

Vode Revit User Guide


Adding Light to Vode Revit Files

Before you begin:

- 1: Download the Revit file for the desired fixture type and mounting from the Vode Website **Resources** tab.
- 2: Download the IES .pdf and .ies Light files for the fixture optics and output desired from the Vode Website **Resources** tab.
- 3: Open the Revit Family file. NOTE: Vode Revit files are compatible with Revit 2016 or newer.


Step 1: Turn on Light Source

Click the **Family Category and Parameters** icon.




Locate the **Lighting Fixture** menu.

Check the **Light Source** box to turn on a generic light in the model. Click **OK**.




Step 2: Add IES File

Select the light source (*it will turn from yellow to blue*) that was added to the file This will allow you to select the **Light Source Definition** menu.



Change the light source shape to **Linear** and light distribution to **Photometric Web**.



Click the **Family Types** icon and add the desired IES file in the **Photometric Web File** line.

